

LaserCon Dip-switch settings - Rev.2.00

Program Space	Switch 1	Switch 2	Switch 3	Switch 4
Future Use	0	0	0	0
Future Use	1	0	0	0
Future Use	0	1	0	0
Future Use	1	1	0	0
Future Use	0	0	1	0
M.A.C.H. 3 PR-8210 mode	1	0	1	0
DL / SA LD-V1000 mode	0	1	1	1
DL / SA PR-7820 mode	1	1	1	0

0 = off
1 = On