

LaserCon Dip-switch settings - Rev.3 -> Rev 4.2

Program Space	Switch 1	Switch 2	Switch 3	
Switch 4				
Future Use	0	0	0	0
Future Use	1	0	0	0
Future Use	0	1	0	0
Future Use	1	1	0	0
Space Ace w/'91 disc - V1000	0	0	1	0
M.A.C.H. 3 PR-8210 mode	1	0	1	0
DL / SA LD-V1000 mode	0	1	1	1
DL / SA PR-7820 mode	1	1	1	0

0 = off

1 = On